

INDASH by PANAVISE®

I-75138-206

Page 1 of 1

MOUNTING LOCATION:

Right side of radio JR

TOOLS REQUIRED:

Hook tool

Phillips screwdriver

HARDWARE INCLUDED:

None

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#: 75138-206

MFG: VW

MODELS & YEARS: Passat 2006-2010

Passat Wagon 2007-2010, CC 2009-10

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1 With hook tool assist remove the bezel around the radio by starting at the bottom. There are (4) clips to release. Set bezel aside

STEP #2 With T-20 Torx driver, remove the lower right radio screw. Place InDash by PanaVise Mount over screw holes and replace screws. Replace the bezel

INSTALLATION IS NOW COMPLETE.
ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Radio bezel removed



InDash installed showing location



Mount in place showing screw.



03-08-10